

SCALE DISSOLVER

For dishwashing machines, glass washers, coffee machines, etc.

DESCRIPTION: Scale Dissolver is a non-foaming cleaner that can be used for descaling dishwashers and glass washers. It contains a special blend of acids and non-foaming detergents.

DIRECTIONS: Circulate or soak for about 10 minutes with a solution of 1 part Scale Dissolver to 4 parts of water. Drain and rinse. For major scale build up, use a stronger solution and a contact time of up to 4 hours.

CAUTION ACID: Do NOT mix with other chemicals and avoid contact with aluminium.

The Canadian Food Inspection Agency has no objection to the use of this product in food plants when used according to label directions.

FOR COMMERCIAL USE

