

E-Z DESCALER

For dishwash machines, glass washers, coffee machines, ice machines, water distillers, etc.

DESCRIPTION: This product is a concentrated food grade non-foaming cleaner that can be used for descaling dishwashers. It contains acid and non-foaming detergents and has no objectionable odour. It is an ideal product for descaling.

CAUTION ACID. Do NOT mix with other chemicals. Avoid contact with aluminum.

DIRECTIONS: Circulate or soak for about 10 minutes with a solution of 1 part product to 4 parts of water. Drain and rinse. For major scale build up, use a stronger solution.

FOR COMMERCIAL USE

